



FIGURE 5

HEADRAIL & HEADRAIL BRACKETS

- Level headrail in notched slots in pilasters from one compartment to the next. Tighten height adjustment screws at bottoms of pilaster.
- Drill $11/64$ holes and fasten headrail to pilaster with $\#14 \times 1/2$ " sheet metal screws.
- Drill $11/64$ holes and attach "U" bracket to end pilaster with $\#14 \times 1/2$ " sheet metal screws.
- Drill $5/16$ " holes in wall, insert Plastic anchor and secure headrail wall bracket with $\#14 \times 1/2$ " sheet metal screws.
- Place headrail into brackets and secure with $\#14 \times 1/2$ " sheet metal screws.

HANG DOORS & ACCESSORIES — ALL TYPES

- Refer to Fig. 6 for hanging of doors and attachment of accessories.
- Touch up as required.